5. How to use BoardDiag(2)

3) Restore Device

1. Select **AP chipset**
2. Select **Com Port**
3. Select **Tartget Dir**
- Refer to chapter 6 (1) Image Extraction
4. Choose **AP check**
5. Choose **RESTORE BOOT IMAGE**
- Option X
6. **START**